

RedPortTM

Optimizer Premier

Installation and Setup Guide

Table of Contents

1. Overview.....	3
2. Setup Requirements.....	4
3. Connection to the Device.....	5
4. Router Interface Addresses.....	5
5. Router Admin Login.....	6
6. Setup Option #1: Default Setup.....	7
7. Setup Option #2: CP Disabled Setup.....	7
8. Setup Option #3: Alternate Setup.....	9
9. First Use With Captive Portal Enabled....	10
10. Captive Portal Usage.....	11
11. Router Administration.....	11
12. Network-wide Web Compression.....	12
13. Email Subaccounts.....	12
14. PBX Voice Setup.....	13
15. Multi-VoIP (Multi-User VoIP).....	14
16. Enable RedPort VoIP Service.....	15
17. Voice Using Your Satellite Airtime.....	15
18. Factory Default.....	17

Overview

Satellite broadband terminals and devices allow you Internet connectivity almost everywhere on the planet. With this amazing functionality, comes the risk of very high airtime bills.

Optimizer Premier allows you precise control over who can access your satellite Internet connection, as well as how they can use that connection. This gives you great flexibility to control your satellite airtime and helps prevent unwanted airtime bills.

Optimizer Premier helps prevent billshock in the following ways:

- By default, its built-in firewall blocks all Internet activity except RedPort Compression Email services, XGate phone, and RedPort compression web browsing.
- Its built-in Captive Portal allows you to restrict web activity. You can generate PIN-codes that can be given away or sold to control web access.
- The unit can be configured to allow other kinds of traffic (say, apps on a phone), while still giving you control over usage.
- Email with RedPort is compressed up to 95% of its original size, meaning lower data usage and faster data transfer.
- Web browsing can be compressed by a factor of 3 to 5, allowing for faster data transfer and lower data usage.
- Using the local WiFi network, you can assign unlimited phone extensions and make simultaneous calls, texting, and email between users - without using your satellite airtime. It all goes over the local WiFi network.
- With RedPort VoIP Service and a compatible satellite terminal, it turns your satellite connection into a multi-user unit with multiple users sending/receiving VoIP calls at one time.
- Using the RedPort VoIP service, you can make voice calls for sometimes considerably less than traditional satellite phone voice rates. These VoIP calls consume approximately 15 minutes of talk time for each Mb of data. (Compare this to services like Skype which only offer about 1 minute of talk time per Mb of data)

- You can also make simple analog voice calls with traditional satellite airtime using your smartphone by using the VoIP-to-Circuit-Switch capabilities of Optimizer Premier.

Setup Requirements

The following hardware and software is required:

- Satellite broadband terminal
- RedPort Optimizer Premier
- XGate Phone App for your iOS or Android device (required to use RedPort VoIP service).
- For iSavi Only: IsatHub Control App
- RedPort-certified compression data service (like XGate, MVSMail, SpeedMail, etc).

Connecting to the Device

You can connect to the Optimizer Premier by connecting your satellite broadband terminal to one of the two WAN ports labeled SAT and SAT2.

Alternately, administrators can access the unit through one of the WAN ports.

Router Interface Addresses

Captive portal is enabled, the router admin page is accessed via 10.1.5.1 into the URL bar of a web browser. (Note: this is its default state).

When the captive portal is disabled, the admin page can be accessed by entering 192.168.10.1 into the URL bar of a web browser.

Other useful addresses:

Captive Portal: 10.1.5.1

LAN/WiFi Bridge: 192.168.10.1

BIZ/LAN: 192.168.11.1

SAT (WAN): DHCP

SAT2 (WAN): DHCP

WiFi SSID: wxa-165-XXXX (XXXX is a unique identifier for your device)

The Wifi port is used with our RedPort Halo Long Range Wifi Extender system, to repeat nearby internet across the Optimizer Premier.

Router Admin Login

There are two levels of administrative access for the Optimizer Premier:

“Admin” access is designed for the onsite administrator who may not have the technical knowledge required to configure the router. Basic functions (like creating PIN codes, managing users, viewing CDRs (usage records) and creating subaccounts) can be accessed, but more advanced features like router and network configuration require “superadmin” access.

Router admin account info:
Username: admin
Password: webxaccess

“Superadmin” access is designed for the installer/technician/network administrator. It allows full access to the user interface for setup, configuration, and maintenance of the router.

Router superadmin account info:
Username: superadmin
Password: webxaccess

Setup Option #1 : Default Configuration

No router changes or configuration is required when using a RedPort-certified compression email program like XGate or compression web-browsing client XWeb. The router is configured to allow this traffic through.

XGate/XWeb users should refer to the RedPort Optimizer Quick Start Guide when using Optimizer Premier. This guide can be found online at <http://www.redportglobal.com/support/documentation-manuals/>

Default configuration works well for bandwidth over-utilization protection, you can give users more freedom of Internet use and still control overall usage costs.

With the default setup, users must log in through the captive portal before they can access the Internet. Once logged in, they can access whatever they want (as long as it is not on a predefined filter or firewall list).

A good thing to remember, however, is that once they are logged in, their computers can generate unwanted usage that consumes

their PIN codes quickly. Users can also use Skype and other P2P applications that require a lot of bandwidth.

Note: The BIZ (LAN) port does not have captive portal enabled, and will allow all internet traffic.

The Crew Line has captive portal enabled and will have all the same restrictions as the wifi with captive portal enabled.

Setup Option #2: Captive Portal Disabled Setup

To use the Optimizer Premier without Captive Portal, the wifi and Crew/LAN port will act like the BIZ/LAN port of the router. There will be nothing blocking any internet traffic.

To configure the Optimizer Premier with the Captive Portal Disabled setup:

1. Login to the Optimizer Premier admin portal.
2. Navigate to Services > Crew Internet Access > Settings
3. Uncheck the box under “enable” to enable the Captive Portal
4. Select “Save and Apply” at the bottom of the screen.
5. Router will reboot and you can then access the UI by typing 192.168.10.1 in the URL bar of a web browser.

Setup Option #3: Alternate Setup

The following configuration blocks all traffic to the Internet. Users must log in though the captive portal to have access to HTTP and HTTPS traffic. All other traffic is blocked, preventing Skype, apps on smartphones, and other P2P applications from working. This setup also has the advantage of passing HTTPS traffic through

the filtering proxy server that allows the administrator to block sites.

When using this alternate setup, users will need to change the default settings in their web-browsers and use the direct captive portal login link to login.

The following procedure will enable the alternate setup:

1. Log in to the Optimizer Premier admin portal.
2. Navigate to Network > Firewall > Traffic Rules
3. Uncheck the first 6 rules at the top of the list labeled “XX - DO NOT MODIFY” where XX is ALL, PASS DNS, DNS, HTTP, HTTPS, and FTP
4. Select “Save and Apply” at the bottom of the page. This will modify the firewall to block access to all traffic, including DNS.
5. Instruct the end user to modify their browser configuration to enable “Automatic Proxy Detection”. For Firefox this is done under Preferences > Advanced > Network > Settings by selecting “Auto-detect proxy settings for this network”. Other browsers can be configured similarly.
6. Instruct the user to use the captive portal URL to access the login page. This is done by entering <http://10.1.5.1:4990/www/login.chi> in the browser.
7. Once logged in, the user will have access to all http and https websites.
8. Entering <http://logout> will log the user out of the captive portal and end his session. Alternately, the user could use the status page at <http://10.1.5.1:4990/www/status.chi> and log out from there.

First Use with Captive Portal Enabled

Users must log in through the captive portal before they can access the Internet. To log in, open a browser and enter a URL such as <http://www.amazon.com>. The captive portal will intercept the request and redirect the user to a login page. A valid username/password or pincode must be entered before access to the Internet is granted.

Once logged in, any application (web based or otherwise) should have access to the Internet, unless it has been blocked by filter rules or the firewall.

Captive Portal Usage

As stated above, entering an http:// URL into a browser redirects the user to the captive portal login page. Alternately, users can access the captive portal directly using one of the following URLs.

Login – <http://10.1.5.1:4990/www/login.chi>

Status – <http://10.1.5.1:4990/www/status.chi>

Logout – <http://logout>

The captive portal status page provides status information for the current active session such as:

- **Max Session Time:** maximum allowed time before user is forcibly logged off.
- **Max Idle Time:** user is logged off automatically if no traffic is observed within this period.
- **Start Time:** session start time.
- **Idle time:** time of idle activity.

- **Downloaded:** amount of data transferred to the user.
- **Uploaded:** amount of data requested by the user.
- **Original URL:** URL that initiated the login request.

Users can end a captive portal session by either clicking the logout link on the status screen or by entering <http://logout> in their browser.

The captive portal ships configured with two accounts. They are:

- admin/webxaccess
- test/1234

The admin account is open and has no restrictions. The test account is restricted to 10Mbytes of total usage at a speed of 128kbps.

Router Administration

In default configuration, the router admin page is accessed via <http://10.1.5.1>. This URL will not work when the captive portal is disabled and not in use.

When the captive portal is disabled, the router admin page is accessed via <http://192.168.10.1>.

Network-wide Web Compression

You must have a valid web compression account before using this feature. Please contact your RedPort dealer and request a username and password for the compression service.

Once you have your account information, log in to the router and browse to Services > Web Compression and Filtering > select the Compression tab.

Check the Enable Compression option and enter your assigned credentials. Click <Save & Apply>.

You should now be able to browse the Internet with compression enabled.

Email Subaccounts

While users can generally check their primary emails using a web browser (say, with a Gmail account), this tends to be a very high data usage activity, is a slow experience for the user, and drives up airtime costs.

A much better solution is to use RedPort Email subaccounts for crew, work teams, passengers, or guests. These compression email accounts run directly on the Optimizer Premier and can be accessed via a webmail interface on the local network.

You must have a valid RedPort email subscription in order to use email subaccounts on the Optimizer Premier. Please contact your RedPort dealer and request a username and password for the RedPort email service.

Once you have login information for RedPort email service, go to Services > RedPort Email and enter in your userid and password into the “General Settings” tab on the bottom half of the screen.

Click “Save and Apply”

You can then click on the “Home” tab, scroll about halfway down the page to the “Email management” section, and click on “Create and Manage Crew Email Accounts” button.

In this section, you can add sub accounts for Optimizer Premier email.

PBX Voice Setup

Optimizer Premier has a full-featured PBX that allows you to have unlimited extensions, free local area calling, and SMS. By default, 4 extensions have been created in the system.

201 - Default: Enabled for both inbound and outbound calling and inbound and outbound SMS

202 - Default: Enabled for outbound calling and outbound SMS only

203 - Default: Enabled for outbound calling and outbound SMS only

204 - Default: Enabled for outbound calling and outbound SMS only

The PBX settings can be found in the router's user interface under Services > Voice PBX. This is where you can change and enable SIP extensions and register for RedPort Multi-VoIP service.

Multi-VoIP (Multi-user VoIP)

Optimizer Premier allows for multi-VoIP calling (multiple incoming/outgoing calls and SMS all at the same time) when using the optional RedPort VoIP service. With RedPort VoIP service, you get a phone number assigned to you (for a nominal monthly fee) and pay very small termination rates for outbound calls - generally in the realm of \$0.16 per minute.

VoIP calling consumes your satellite data airtime and, depending on your airtime plan, can overall be less expensive than traditional satellite voice calling.

RedPort VoIP service allows up to 4 concurrent calls at once. With RedPort's industry-leading compression rates, you get 15

minutes of talk time per MB of data consumed. (Compare this to a service like Skype, which consumes around 1 MB of data per minute of talk).

Call payment methods include:

- Prepaid PIN codes to help you stay on budget and/or support revenue generation
- PIN codes can be given away or sold to crew/workteams/guests
- Postpaid lines are billed monthly for actual usage
- No charge for calls and texting among local SIP extensions when on the Optimizer Premier WiFi network

Enable RedPort VoIP Service

Contact your satellite service provider to purchase the RedPort VoIP service.

When the service is activated, you will be given a “Key.” This key is a long alpha-numeric string that must be entered into the Optimizer Premier web interface.

Login to the Optimizer Premier web interface and select Services > Voice PBX > RedPort VoIP

How to Enable Voice Using Your Analog Airtime

While RedPort VoIP service may not work on all satellite broadband terminals, making traditional satellite voice calls through Optimizer Premier does work. This is called VoIP-to-Circuit-Switch calling, and allows you to use a smartphone to

make a VoIP call via WiFi using your standard satellite airtime rates.

Optimizer Premier's VoIP-to-Circuit-Switch feature works differently depending on which satellite terminal you have.

Inmarsat Sailor Fleetbroadband Terminals

Sailor 150, Sailor 250, and Sailor 500

Please ensure that DHCP is enabled on your Sailor terminal. Refer to your Sailor user manual for instructions on how to turn on DHCP.

Connecting your Sailor Fleetbroadband terminal to Optimizer Premier via Ethernet will automatically enable VoIP-to-Circuit-Switch.

Unless you have RedPort VoIP service enabled, all outbound voice calls will automatically use your standard satellite airtime rates.

The only time you will need to go to the "Sailor" tab in the Optimizer Premier user interface is if your Sailor FleetBroadband terminal is not your primary device (ie: if it is being used for failover with a VSAT system), if you have changed the password for the Sailor 501 extension, or if you want to use a different extension than 501. (This may be the case if you have IP phones plugged into your Sailor system).

If any of these cases is true, you will need to go to Services > VoIP PBX > Sailor FBB and

1. Input the IP address of the terminal (refer to the Sailor user manual or your installation technician for this address).
2. Change the extension number.
3. Change the password for that extension.
4. Hit "Save and Apply"

Inmarsat IsatHub iSavi

Please refer to the Optimizer Voice iSavi Addendum for information on how to pair the iSavi with the Optimizer Premier

All Other Satellite Broadband Terminals

Iridium Pilot, any non-Sailor FleetBroadband, BGAN, VSAT, and more

All of these devices require the optional Optimizer Premier accessory: **Optimizer Premier ATA for Analog Calling**. With the ATA connected, the Optimizer Premier will automatically enable VoIP-to-Circuit-Switch conversion.

Contact your RedPort satellite dealer if you need to purchase the Optimizer Premier ATA.

Factory Default

Optimizer Premier can be reset to factory default by pressing the reset button on the back of the router for 15 seconds and then releasing it. The router will then reboot and start backup with its default settings.

Please refer to the Optimizer Premier Advanced User Guide for more information.



www.globalmarinenet.com